


Byte av temperaturgivare till MFPH värmekapsel Changing thermocouple for MFPH heater



ALT.

1. +Positive=Röd/Red (magnetic)
-Negative=Blå/Blue
2. +Positive=Svart/Black (magnetic)
-Negative=Vit/White
3. +Positive=Vit/White (magnetic)
-Negative=Röd/Red